


**pentashot** 

# Target Hit&Miss Connect



<a href="#"><u>Safety notes and important information</u></a> .....	<a href="#"><u>4</u></a>
<a href="#"><u>Description</u></a> .....	<a href="#"><u>5</u></a>
<a href="#"><u>Purpose</u></a> .....	<a href="#"><u>5</u></a>
<a href="#"><u>Preparing the target for use</u></a> .....	<a href="#"><u>6</u></a>
<a href="#"><u>Power source</u></a> .....	<a href="#"><u>6</u></a>
<a href="#"><u>Technical data</u></a> .....	<a href="#"><u>9</u></a>
<a href="#"><u>Warranty</u></a> .....	<a href="#"><u>10</u></a>
<a href="#"><u>Storage</u></a> .....	<a href="#"><u>11</u></a>
<a href="#"><u>Replacement parts</u></a> .....	<a href="#"><u>12</u></a>
<a href="#"><u>Disposal</u></a> .....	<a href="#"><u>12</u></a>

# Safety notes and important information

## Before use

- ◆ Keep the target clean; wipe off dust with a dry cloth.
- ◆ Never use detergents, solvents or chemicals.
- ◆ Never press any objects against the front surface of the target.
- ◆ Check the battery in the target periodically for corrosion or leakage.
- ◆ If you will not be using the target for more than a week, we recommend removing the battery.
- ◆ Also remove the battery before travelling by plane.
- ◆ The target should be positioned so that sunlight does not directly hit the front surface of the target.
- ◆ The laser target is an optoelectronic device, its disassembly is prohibited !!!


## During use

- ◆ When handling the target, follow the general rules for handling real weapons.
- ◆ When using the target in a room with artificial lighting, the proper function of the target may be interfered with, if the light source operates at 40 kHz.
- ◆ Laser emitters with inferior optics may cause incorrect scoring when fired at distances less than 5 metres and at low light levels.
- ◆ The target can be fired with all laser emitters or simulators with a UIPM laser code of 15.6 ms.

## After use

- ◆ After use, place the target in its original case.
- ◆ Protect the target from direct sunlight and rain in accordance with UIPM rules

# Description



1 – Hit&Miss target

2 – Hit zone

3 – Miss zone

4 – LEDs

5 – Battery

6 – On/Off button (START)

7 – Mounting holes

8 – Connector for external lamps and programming cable

## Purpose

The Hit&Miss target is for instruction, training and competition for the laser run in

modern pentathlon. The target evaluates the laser beam shot to the hit zones. A shot to the hit zone is signalled when a green LED lights up. A shot to the miss zone is signalled when a red LED lights up. Shooting time is 50 seconds from the first shot to the target's front surface. After 40 seconds, the first LED on the left flashes slowly for 5 seconds, and after 45 seconds it starts to flash quickly. After 50 seconds, all LEDs flash for 5 seconds. All LEDs also flash after the fifth successful shot to the hit zone. The target runs on two 1.5V AA batteries.



ATTENTION - YOU CAN ONLY USE A POWER BANK WITH THE PARAMETERS LISTED IN THIS MANUAL! OTHERWISE THE TARGET MAY BE DESTROYED!

## Preparing the target for use

The target can be mounted on the tripod using the HIT Compact Pentashot target holder or on the wall using the hanging holes /6/. The mounting of the target must be firm and stable, especially in windy weather. If the target falls to the ground it may be damaged.

## Power source

The target is powered by two AA 1.5V batteries or a power bank with the following specifications:

- ◆ output voltage maximum 5V
- ◆ minimum power bank output current 2.4 A (ideally with USB-C output, which has a 3A output)
- ◆ the total capacity of the power bank should not be less than 10000 mAh


## Turning on

Insert two 1.5V AA batteries into the battery compartment — CAUTION: Make sure to get the polarity right (according to the instructions on the sticker in the battery

compartment). Place the target on a level surface or use the holes to hang it on a wall or other prepared surface. Turn the target on with the START button.

After it is turned on, first the green LEDs go on and then the red ones (for just a few seconds). Then the target automatically checks its battery status by lighting up the green LEDs:

- ◆ 5 green LEDs – fully battery
- ◆ 4 green LEDs – battery at 75%
- ◆ 3 green LEDs – battery at 50%
- ◆ 2 green LEDs – battery at 25%
- ◆ 1 green LED – battery dead; replace it



## Turning off


You can start shooting at the target. The target automatically shuts off 20 minutes after the last shot. The target can also be turned off by pressing the START button for about 5 seconds. An audible signal shows it has been turned off.

## Replacing the battery

Remove the batteries from the battery compartment using the battery tape and insert new batteries.



Make sure the polarity is correct and insert the batteries according to the instructions in the battery compartment.





## LED light brightness power supply

If you have a target with serial number HM-8236 or higher, you can use the START button to adjust the brightness of the LED lights after turning on the target.

The setting allows you to switch between lower and higher LED light brightness by pressing the START button. When the target is set to a lower brightness, the light next to the button glows red. When the START button is pressed, the higher brightness of the LED lights is set, the light next to the button is green.

## Update function

App updates appear in Google Play (Android) and AppStore (Apple iOS).

The target can be updated only by the manufacturer or an authorized person.

## Technical data

Dimensions	270 mm x 190 mm x 32 mm
Size of HIT zone	Æ 59,9mm
Size of MISS zone	180 mm x 175 mm
Weight	684 g with batteries
Shooting distance	From 5 to 10 metres
Shooting time	50 seconds (one round)
Power source	Two 1.5V AA batteries (alkaline recommended) USB cable from the electrical grid

Laser code type	UIPM laser signal 15.6 ms or 25.2 ms
Sunlight resistance	120 000 lux
Compatible external lamps	NAVISTREET
Operating temperature	10°C to 50°C
Degree of casing coverage	IP52
Update function	Google Play and AppStore
Compatible operating system versions	Minimum is Android 4.3 or iOS 11
Integrated signal lights	YES
Tripod mount	NO
Integrated hanging system	YES

## THE USER CAN CARRY OUT THE FOLLOWING MAINTENANCE AND SETTINGS:

- ◆ battery replacement



It is forbidden to open or modify the electronic target, except to change the battery. Only the manufacturer or an authorised person may change the software parameters. The owner of the target must agree to the change in writing. The manufacturer will not accept any liability for damages resulting from such a change.

## Warranty

A warranty repair shall apply exclusively to defects that have provably arisen during the effective warranty period, namely as a result of a material defect or a manufacturing defect. Defects arising in such a manner may be remedied only by the manufacturer or an authorized maintenance and service center. The buyer can make a claim under the warranty against the manufacturer or authorized dealer, as the case

may be.

The warranty period shall become effective on the day of purchase or delivery of the Goods to the Buyer, and the warranty remains valid for 24 months.

In particular, the following cases are excluded from the warranty repair:

- ◆ The product has not been returned to the dealer/manufacturer with the proof of purchase.
- ◆ Wear and tear due to the use of the product or damage to the product (incl. damage caused by unskilled installation, improper commissioning, non-compliance with the procedures defined in the instructions for use, etc.).
- ◆ Damage to the product caused by contamination, an accidental or disaster event or occurring as a result of natural or external events such as a storm, fire, water, excessive heat or chill, ingress of a liquid, etc.
- ◆ Mechanical damage to the product (e.g. caused by fall, breaking, etc.) or damage arising during the transportation.
- ◆ Damage, unauthorized design modifications, improper modification of the product or any other interventions in the product conducted by unauthorized persons or maintenance and service centers.

## Storage

It is very important that the target be stored under the right conditions, so that it will stay reliable and in good condition. Always do the following:

- ◆ Before storing the target for an extended time, always remove the batteries. This prevents damage to the inside of the target if the batteries leak.
- ◆ Store the target in the original package (case) in a dry, dark location out of the reach of children.
- ◆ Do not place any heavy objects on the case, or objects that may leak fluids.
- ◆ Protect the target from weather, including frost and humidity. The optimal storage

- ◆ temperature is +5°C to 30°C. The air humidity at the storage location must not exceed 60%. Do not store the target in a damp environment where there is a high risk of corrosion.

## Replacement parts

The following spare parts are available for the targets:

- ◆ front face
- ◆ LED lights
- ◆ battery holder
- ◆ PCB
- ◆ target box

Spare parts can be ordered by email at [sales@pentashot.com](mailto:sales@pentashot.com) or from PENTASHOT partners and dealers. You can find a list of them at [www.pentashot.com](http://www.pentashot.com).

Replacement of major parts may only be carried out by the manufacturer or an authorized person.

## Disposal



Once the Hit Compact target ends its lifetime, do not dispose of it along with other household waste. Take it to a waste disposal site of raw materials or let it be disposed at a specialized company capable of recycling such a material.

Used batteries must not be thrown out with standard household waste. Take all used batteries to specialized collection locations.